

QUEEN'S UNIVERSITY IONIC LIQUID LABORATORIES

QUILL

Waste plastic valorisation using acidic ionic liquids

**Emma McCrea** 

Supervisors: Prof. Gosia Swadźba-Kwaśny Prof. John Holbrey

QUILL meeting, 25-26<sup>th</sup> March 2024 – Confidential

### **Project overview**



Low value plastic waste

**Chemical recycling** 











### Motivation for this project



- Industry standard to produce base oil from 1decene and uses BF<sub>3</sub> as a catalyst which poses a significant safety risk
- Previous publications successfully used liquid coordination complexes and borenium ionic liquids with physical properties comparable with commercial grade base oil
- This work aims to replace 1-decene with waste polyolefin plastic
- \$576 million in 2020 to \$798 million by 2025<sup>1</sup>





PAPER

View Article Online
View Journal | View Issue



Liquid coordination complexes: a new class of Lewis acids as safer alternatives to  $BF_3$  in synthesis of polyalphaolefins

James M. Hogg, Fergal Coleman, Albert Ferrer-Ugalde, Martin P. Atkins and Małgorzata Swadźba-Kwaśny\*



Research Article


pubs.acs.org/journal/ascecg

### Borenium Ionic Liquids as Alternative to BF<sub>3</sub> in Polyalphaolefins (PAOs) Synthesis

James M. Hogg, †, Albert Ferrer-Ugalde, † Fergal Coleman, †, and Malgorzata Swadźba-Kwaśny\*, †

<sup>†</sup>The QUILL Research Centre, School of Chemistry and Chemical Engineering, Queen's University Belfast, Belfast BT9 5AG, U.K. <sup>‡</sup>Recycling Technologies, Unit 2, Stirling Court, Stirling Road, Swindon SN3 4TQ, U.K.

§Trifol Resources Ltd, Unit 1, Clonminam Business Park, Portlaoise R32 P380, Ireland



1-decene

### **Plastic**





ĊH<sub>3</sub>

"Plastics"
Synthetic polymers



QUEEN'S UNIVERSITY
IONIC LIQUID
LABORATORIES
QUILL





### Types of recycling




QUEEN'S UNIVERSITY
IONIC LIQUID
LABORATORIES
QUILL

#### **Chemical recycling**

## Mechanical recycling Collection Sorting **Shredding** Washing Reprocessing

#### **Depolymerisation**



Ionic liquids can be used as an alternative to H<sub>2</sub>SO<sub>4</sub>.

ACS Sustain. Chem. Eng., 2021, **9**, 15157–15165

#### Gasification

Plastic waste



Oxygen and steam



**Syngas** 

A reaction with a gasifying agent (steam) at high temperatures

#### **Pyrolysis**

Plastic waste



Oxygen deficient




Hydrocarbon fractions

Thermal degradation in an oxygen deficient environment at high temperatures

### Recycled feedstock reaction



QUEEN'S UNIVERSITY
IONIC LIQUID
LABORATORIES
QUILL




Recycled feedstock

Ur-AlCl<sub>3</sub>: 0.28 mmol/ml

Quenched with water to remove catalyst

Removal of aqueous layer

Optimised catalyst loading for 1-decene reaction Ur-AlCl<sub>3</sub>: 0.028 mmol/ml




ACS Sustain. Chem. Eng., 2019, 7, 15044-15052.

### Results



- Based on previous work on 1-decene using liquid coordination complexes and borenium ionic liquids the expectation was that oligomerisation would occur increasing the product distribution of heavier oligomers.
- However, this was not the case and hydrocarbon cracking, and oligomerisation was observed.
- This can be explained from the balance between the exothermic reaction (oligomerisation) and endothermic reaction (hydrocarbon cracking)




# Waste polyolefin feedstock results: Light fraction



QUEEN'S UNIVERSITY
IONIC LIQUID
LABORATORIES
QUILL

Results obtained by SimDist GC and mass balance as light hydrocarbons evaporated






## Waste polyolefin feedstock results: Heavy fraction



QUEEN'S UNIVERSITY
IONIC LIQUID
LABORATORIES
QUILL

Oligomerisation




Oligomerisation occurred with the fraction containing heavier hydrocarbons

Different selectivity towards cracking and oligomerisation depending on the composition of the fraction

Hydrocarbon cracking

## Waste polyolefin feedstock results : crude feedstock





**Increase 20 °C** to ensure the feedstock slurry was liquid on addition of the catalyst


Strength of Lewis acid impact product distribution


### **Conclusions: Polyolefin recycling**



- Competition between cracking and oligomerisation reaction
- Endothermic C-C cleavage vs exothermic reaction
- Heavy feedstock: oligomerisation of feedstock to lubricant base oil range
- Light feedstock: cracking feedstock toward fuel range
- High sensitivity towards feedstock, Lewis acidity, catalyst loading and reaction parameters

# Moving on: Polyethylene terephthalate (PET)




















## **PET recycling**







### Reasoning and industry standard



- Industrial standard is mechanical recycling which leads to continuous degradation of the plastic.
- Garbo Chempet©: producing 55-65 ton per day of BHET production
- Eastman methanolysis technology producing DMT using temperatures over 200 °C
- Depolymerisation of PET with Brønsted acidic ionic liquids:
   high reaction temperatures between 200 400 °C
- Can we develop a method that utilises ionic liquids to produce an energy efficient process?



Sorting and mechanical recycling

### Method





PET water bottle purchased from local supermarket

Washed, dried and cut into 1 cm<sup>3</sup> x 1 cm<sup>3</sup> squares

Mesh sieve to achieve uniform power

Add Brønsted acidic ionic liquid and methanol

Formulated from tributylamine (N<sub>444</sub>) and sulfuric acid from earlier published work <sup>1</sup>

### Microwave depolymerisation



- Ionic liquids efficiently absorb microwaves through an ionic conduction mechanism, rapidly reaching high temperatures.
- This combination enables an energy-efficient method to achieve higher temperatures at lower energy costs.
- $[N_{444}H][HSO_4].H_2SO_4 \chi_{H2SO4} = 0.67$





ÉVA BOROS KENNETH R. SEDDON CHRISTOPHER R. STRAUSS

## Chemical processing with microwaves and ionic liquids



Èva Boros, Kenneth R. Seddon, Christopher R. Strauss, Chemistry today, 2008, **6**, 26

### **Future work**



- Optimise PET reactions conditions using Brønsted ionic liquid catalyst
- Measure percentage conversion of PET using a mass balance
- Access the purity of DMT by GC-MS and NMR spectroscopy
- Investigate the reusability of the Brønsted ionic liquid catalyst

### Acknowledgements



- Prof. Gosia Swadźba-Kwaśny
- Prof. John Holbrey
- Quill Research Centre

